



Rugged Ridge 2007 Wrangler Grab Handle Installation Instructions.



Installation instructions for 13305.10 & 13305.11 (head rest)

Step1 – raise headrest to upper most position. Press both lock tabs inward to release headrest from seat. (Fig.1)

Step2 – Insert headrest support shafts through grab handle loops. Reinstall headrest and set to desired position. (Fig.2)

Fig.1



Fig.2

