



**Step 1.** Remove the three bolts that retain the factory door mirror. Remove the factory mirror.



**Step 2.** Remove the two side door hinge bolts. The factory uses threadlock to retain these bolts, so some effort may be required.



**Step 3.** Using the included hardware, install the relocation bracket using the existing factory door hinge bolt holes. Install both bolts loosely. Note that the relocation bracket points forward.



**Step 4.** Tighten both bolts snugly.



**Step 5.** The relocation bracket is now installed.



**Step 6.** Place the factory mirror onto the relocation bracket, taking care to align the mounting bolt holes. Using the included hardware, insert the bolts through the mirror and bracket mounting holes.



**Step 7.** Place one washer on each bolt, followed by one nut (included). Tighten the nuts snugly, taking care not to over tighten.



**Step 8.** Installation is now complete. Repeat procedures for other side.

