### WRANGLER 2007-2012

Table Of Contents

#### INTERIOR F

FLOOR LINERS	J24
GRAB HANDLES	J35
HARD TOP INSULATION	J23
HEAVY-DUTY OFF ROAD	J43-J44
ACCESSORIES	J43-J44
INTERIOR STORAGE	J26
INTERIOR TRIM	J29-J31
OFF ROAD ACCESSORIES	J53
ORGANIZERS	J25-J26
OVERHEAD CONSOLES	J25
INTERIOR ACCESSORIES	J33-J35
SEATING	J27-J28

### PERFORMANCE

AIR INTAKES	J45	
DUAL BATTERY TRAY	J47	
HEADERS/EXHAUST	J44	

### EXTERIOR

BLACK EXTERIOR ACCESSORIES	J36-J38
BODY ARMOR	J39
BUMPER SYSTEMS	J8-J12
COVERS	J23
DOORS	J32
DOOR ACCESSORIES	J32-J33
EXTERIOR ENHANCEMENTS	J36-J42
FENDER FLARES	J15
OFF ROAD LIGHTING	J49-J52
REPLACEMENT MIRRORS	J33
SKID PLATES	J43
STAINLESS/CHROME EXTERIOR	J40-J42
ACCESSORIES	100
STORAGE BOOT/TIRE COVERS	J22
TOPS/SUMMER BRIEFS/ ISLAND TOPPERS	J18-J21
TUBE STEPS. SIDE PROTECTION	J13-J14
Sector and the sector of the s	12133333710
WHEELS & ACCESSORIES	J16-J17
WINCHES & RECOVERY GEAR	J46-48

#### **SUSPENSION**

SUSPENSION KITS	J55
SHOCKS & STABILIZERS	J56

# AXLE

AXLE KITS	J59
RING & PINIONS	J60
WHEEL SPACERS	J60
AXLE & DIFFERENTIAL COVERS	J60



Wrangler 07-12

### CJ & WRANGLER 1976-2006

Table Of Contents

#### INTERIOR

	INTERIUR	
2	FLOOR LINERS	C20
	GRAB HANDLES	C22
	HEAVY-DUTY	C45-C50
	OFF ROAD ACCESSORIES	
	INTERIOR STORAGE/	C24
	ORGANIZERS	Cheve the
	INTERIOR TRIM	C21
	REPLACEMENT	C22-C23
	INTERIOR ACCESSORIES	
	SEATING	C37-C41
	SOUND ACCESSORIES	C19
	PERFORMANCE	- Aller
		125 130
	AIR INTAKE KITS	C55
	CAT-BACK EXHAUST	C55
	DUAL BATTERY TRAY	C47
	EXHAUST HEADERS	C55
	EXTERIOR	
	BLACK EXTERIOR ACCESSORIES	C27-C28
	BODY ARMOR	C34
	BUMPER SYSTEMS	C2-C9
	COVERS	C15
	DOOR ACCESSORIES	C18-C19.
		C25
	EXTERIOR ENHANCEMENTS	C35
	FLARES & FENDERS	C10-C11
	HEADLIGHT TREATMENTS	C26, C31,
		C54
	OFF ROAD LIGHTING	C51-C54
	REPLACEMENT MIRRORS	C36
	SKID PLATES	C46
	STAINLESS/CHROME	C29-C33
	EXTERIOR ACCESSORIES	
	STORAGE BOOT	C19
	TOPS/SUMMER BRIEFS/	C13-C18
	ISLAND TOPPERS	CARE OF T
	TUBE STEPS	C10
	WHEELS & WHEEL SPACERS	C12
	WINCHES & RECOVERY GEAR	C42-C44
		Report to 10
	CURDENCION	

#### **SUSPENSION**

BRAKE HOSES	C63
POLYURETHANE	C62-C63
SUSPENSION KITS	C60-C61
SHOCKS & STABILIZERS	C59
the second se	J. MOTO MINUT AND AND

### AXLE

FRONT AXLE KITS	C66
LOCKERS	C71
REAR AXLE KITS	C67
RING & PINIONS	C68, C72
WHEEL SPACERS, AXLE	C68- C70
& DIFFERENTIAL COVERS	a state where



## CHEROKEE, GRAND CHEROKEE, LIBERTY 1984-2012

Table Of Contents

### INTERIOR

FLOOR LINERS	X6
INTERIOR STORAGE/ ORGANIZERS	X5
INTERIOR ACCESSORIES	X7
SEATS & SEAT COVERS	X4-X5
Carl I and	30 22
PERFORMANCE	
AIR INTAKE KITS	X16
EXHAUST HEADERS	X16
THROTTLE BODY SPACER	X16
EXTERIOR	AN

#### EXTERIOR

BULL BARS	X2	
BUMPER SYSTEMS	X2	
EXTERIOR ENHANCEMENTS	X8	
FLARES & FENDERS	ХЗ	
HEAVY DUTY ACCESSORIES	X14	G
OFF ROAD LIGHTING	X12-X13	
SKID PLATES	X14	
TOWING	X15	2T-HO
TUBE STEPS	X2	ĥ
WHEELS	ХЗ	
WINCHES & RECOVERY GEAR	X9-X11	

### SUSPENSION


BRAKE HOSES	X21
POLYURETHANE	X21
SUSPENSION KITS	X20
SHOCKS & STABILIZERS	X19

#### AXLE

DIFFERENTIAL COVERS	X26
FRONT AXLE KITS	X24
HUB CONVERSION KITS	X24
LOCKERS	X27
REAR AXLE KITS	X25
RING & PINIONS	X28
WHEEL SPACERS & ADAPTERS	X3, X26
the second se	

lugged Ridge

#### **RESTORATION &** BODY PARTS



# 🛦 WARNING

Your safety and the safety of other motorists is very important. Your Jeep<sup>®</sup> is an off road capable vehicle that readily lends itself to restoration and customization. As the owner of a modified suspension vehicle you are the person choosing the combination of suspension, wheels, tires, drive train and accessories that best fit your intended use. Likewise, you are the person responsible for the safety and legality of the vehicle you modify. In modifying your vehicle's suspension, balance your off-road capabilities against how the vehicle may actually be used off-road and on-road.

It is not practical or possible to warn about all hazards associated with your Jeep" restoration or modifying your suspension for improved off road capabilities. Start by familiarizing yourself with all vehicle manufacturers' instructions and warnings and the instructions and warnings accompanying your aftermarket product. Follow recommended maintenance procedures and routinely inspect your vehicle components for unusual wear or off-road damage. Restoration parts are direct replacements of original components and are not designed or warranted as meeting current safety standards (including FMVSS).

Always wear seat belts and/or appropriate off-road restraints, reduce your speed, tread lightly® and safely enjoy your off-road vehicle.

A FEW WORDS ABOUT PARTS AVAILABLE FROM THIS CATALOG.

PARTS IDENTIFIED AS MOPAR® APPROVED AUTHENTIC RESTORATION PRODUCTS™ REFLECT THAT THE PRODUCT IS LICENSED BY MOPAR® FOR MANUFACTURE BY THIRD PARTIES AND MEETS MOPAR® STANDARDS. OMIX-ADA® AND ITS LICENSEES ARE NOT AFFILIATED WITH CHRYSLER GROUP LLC. ALL PARTS LISTED ARE AFTERMARKET ORIGIN AND PART NUMBERS ARE FOR PURPOSES OF CROSS-REFERENCE ONLY. THE RUGGED RIDGE®,OUTLAND®, ALLOY USA®, AND PRECISION GEAR® PARTS ARE OMIX-ADA® BRANDED PRODUCTS MANUFACTURED BY QUALIFIED THIRD PARTIES. PARTS LISTED OTHER THAN MOPAR® APPROVED RESTORATION PARTS, ARE SUPPLIED BY QUALIFIED OMIX-ADA® VENDORS WORLDWIDE.

THIS CATALOG MAY BE REPRODUCED BY INDEPENDENT RETAILERS UNDER LICENSE FROM OMIX-ADA®. THIS CATALOG REPRODUCED UNDER LICENSE FROM OMIX-ADA INC.

PARTS IDENTIFIED WITH THE MOPAR AUTHENTIC RESTORATION PRODUCT EMBLEM ARE THE ONLY PARTS IN THIS CATALOG OFFICIALLY AUTHORIZED AND LICENSED BY CHRYSLER GROUP LLC.

ALL RIGHTS RESERVED. NO PART OF THIS CATALOG MAY BE REPRODUCED BY ANY MEANS, ELECTRONIC OR OTHERWISE, WITHOUT EXPLICIT WRITTEN AUTHORIZATION FROM OMIX-ADA, INC. © COPYRIGHT OMIX-ADA, INC.

BY ORDERING FROM THIS CATALOG THE PURCHASER AGREES TO THE FOLLOWING TERMS AND CONDITIONS: THIS CATALOG IS BEING DELIVERED AS IS AND OMIX-ADA®, INC. OR LICENSEE MAKE NO WARRANTIES, EXPRESSED OR IMPLIED, ON MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. OMIX-ADA®, INC. OR LICENSEE DISCLAIM ALL LIABILITY FOR DIRECT OR INDIRECT DAMAGES ARISING FROM THE USE OR PERFORMANCE OF THIS CATALOG OR THE PRODUCTS HEREIN. DEFECTIVE ITEMS WILL BE CREDITED OR REPLACED AT OMIX®'S SOLE DISCRETION. OMIX® IS NOT RESPONSIBLE FOR LABOR, CONSEQUENTIAL DAMAGES OR BODILY INJURIES ARISING FROM INSTALLING OR USING ITS PARTS, CATALOG OR LISTINGS. NO RETURNS ARE ALLOWED ON SPECIAL ORDERS, FACTORY DROPSHIPS, ELECTRICAL AND BODY PARTS. OMIX-ADA® OR LICENSEE ARE NOT RESPONSIBLE FOR TECHNICAL ERRORS, OMISSIONS OR PRINTING ERRORS. PRICES, AVAILABILITY AND BRAND NAMES ARE SUBJECT TO CHANGE WITHOUT NOTICE.

JEEP®, WILLYS®, AMC™, WRANGLER™, CHEROKEE™, GRAND CHEROKEE™, LIBERTY™, CJ™, YJ™, XJ™, TJ™, JK™, ZJ™, WJ™, SJ™, KJ™, JEEP® GRILLE DESIGN AND OTHER NAMES USED IN THIS CATALOG ARE TRADEMARKS OF CHRYSLER GROUPLLC. OMIX-ADA® OR ITS LICENSEES ARE NOT AFFILIATED WITH CHRYSLER GROUPLLC. ALL PARTS LISTED ARE AFTERMARKET REPLACEMENT PARTS. PART NUMBERS, ILLUSTRATIONS AND IMAGES USED FOR REFERENCE PURPOSE ONLY. NO IMPLICATION IS MADE THAT THESE ARE ORIGINAL EQUIPMENT PARTS, FROM THOSE SOURCES WHOSE PART NUMBERS ARE USED HERE FOR REFERENCE OR THAT THEY ARE APPROVED BY THOSE COMPANIES.

© OMIX-ADA®, INC. 2011. ALL RIGHTS RESERVED.

All images are subject to be representative. More detailed information is available online.



The following section contain all the parts you need for restoring & repairing your Jeep<sup>®</sup>! From 1941 to current, Omix<sup>®</sup> has you covered. If you know Jeep, you know Omix<sup>®</sup>!



OFFICIAL LICENSED PRODUCT

MOPAR, JEEP, DODGE, HEMI, PLYMOUTH, RAM, and CHRYSLER vehicles, images and logos are trademarks of Chrysler Group LLC used under license to Omix-Ada®. © Chrysler Group LLC 2011





MOPAR, JEEP, DODGE, HEMI, PLYMOUTH, RAM, and CHRYSLER vehicles, images and logos are trademarks of Chrysler Group LLC used under license to Omix-Ada<sup>®</sup>. © Chrysler Group LLC 2011

#### Cook for the star to check out all the Mopar Licensed Products

This emblem is Mopar's "Seal Of Approval" that the product meets their standards and is truly a licensed product.

Parts identified with the Mopar Authentic Restoration Product emblem are the only parts in this catalog officially authorized and licensed by Chrysler Group LLC.

<u>A Few Words About Product Safety:</u> To help you make informed decisions about safety; this catalog and the instructions accompanying our products have provided certain information in the form of "Notices", "Warnings" and "Cautions". This information alerts you to potential hazards that could hurt you or others.



This is a caution against anything which may cause damage to the vehicle or its equipment if the caution is ignored. The Notice includes information about how you can avoid or reduce those risks.

This is a signal telling you that you CAN be KILLED or SERIOUSLY HURT if you don't follow the Warning. The Warning includes information about what you must or must not do in order to reduce the risk of injury to yourself and others.

This is a signal telling you that you or others CAN be HURT if you don't follow the instruction. The Caution includes information about how you can avoid those risks.

#### **Table of Contents**

Body	R1
Axle	R24
Driveshafts	R37
Brakes	R38
Clutch & Flywheel	R48
Cooling	R52
Electrical	R57
Engine	R68
Exhaust	R77
Fuel	R80
Heating & AC	R85
Steering	R86
Suspension	R91
Transfer Case	R95
Transmission	R100
Wipers	R109
Surplus	R111

Parts

#### **INDEX**

#### Index

ADD Canad Canada	R64	Caud
ABS Speed Sensors Accelerator Parts	R64 R80	Cowl Cowl
Air Cleaners	R81	Cross
Air Filters	J45, C55, X16, R81	
Air Intakes	J45, C55, X16	Cup I
Alternators	R57, R111	CV B
Ammeters	R67	Dash Dash
Antennas Axe Clamp	R67 R13	Dash
Axle	K13	Dash
AMC 20	R34-35	Degr
Assemblies	R112	Diffe
Surplus		Lock
Chrysler 8.25"	A5, X25	Diffe Com
Conversion Kits Dana 25	R34 R24	
Dana 27	R24, R29	Diffe
Dana 30	R25-28	Dimr
Dana 35	R32-33, R112	Distr
Dana 44	R28-31, R36	Door Door
Shafts	A1-8, J59, C66-67, X24-25, R24-36	
Snubbers	09, C63, R92-100	Door
Back-Up Lights	C53, U22, R5	Door
Ball Joints	R91	Door
Battery Trays	R9, R11, R67	Door Door
Battery Trays, Dual	J47, C47	Door
Bellcranks Bellhousings	R50-51 R102-103, R108	Door
Black Accessories	J37-38, C27-28	Door
Blackout Lamp Parts	R4	Door
Body		Drive
Armor	J39, C34	Elect
Body Kits	R2	Eng
Fastener Kits	R15, R18	Ĉ
	R3, R10, R15,	Ca
Grilles	R21-23	Bi
Mount Kits	R8-15, R18	Si
Panels	R3, R8-18, R113	Ca
Parts	R1-23	Cr
Tubs	R2, R8-15, R18	S
Brake		Cr Bi
Boosters	R38, R115	Cr
Calipers & Parts	R41	P
Components	R42-47	C) Ga
Drums	R43	0
Emergency Brake Parts	R46-R47	In
Hardware	R39-41	М
Hoses	09, C63, X21	M
Light Switches	R65	Oi Oi
Lines Master Culindera	R39-40 R38	Oi
Master Cylinders Pads	R46	Oi
Pedal Pads	R47	Oi
Pedals	R47	Oi
Rotors	R45	PI Oi
Shoes Slotted Detero	R43	Oi
Slotted Rotors Splash Shields	A10, C69, X26 R45	Se
Bug Deflectors	J36, C26, X8	Oi
Bug Shields	C28, C32	Pi Pi
Bumpers		R
Covers	R18, R22-23	8
End Caps Extensions	R114 R18	Ti
Guards	C9, R21	Ti
Replacement	R16, R18, R21-23	Va Va
Rock Crawling	C8	Entry
RRC Bumpers Tire Carriers	J11, C4	Exh
Tube Bumpers	J10, C4 J11-12, C6-9, X2	Ca
XHD Bumper	J8-9, C2	Co
XHD Rear Bumper	J10, C3	Ca Ki
Car Covers	J23, C15	H
Cargo Liners	U16, J24, C20, X6	H
Choke Cables Clinometer		In
Clocks	U30, C22, X7 R67	M S
Clutch/Flywheel		o In
Flywheels	R49-50	Pi
Kits & Parts	R48-51	M
Master Cylinder Cover Plate	R8, R14	Ta
Pilot Bearings	R49, R71	Exter Fen
Commander Parts	X28	
Consoles	C24	Fe
Cooling		FI
Cooling System Fan Belts	R52-56 R55	Pi Ri
Fan Beits Fan Clutches	R54	RI
Fan Shrouds	R53	Flash
Idler Pulleys	R56	Flex
Radiators & Parts	R52-R53	Floor
Serpentine Belts	R56	Floor
Thermostats Water Pumps	R55 R54	Foot
Charles and the second	AD INCOMENT	

Cowl Panels	R10, R14	Fr
Cowls Seals	R9, R17, R20	Fu
Crossmembers	R21-22 U32, J34, C22, C24,	
Cup Holders	X7, R21	
CV Boots	R37	
Dash Panels	J26, C23, R11, R17	
Dash Parts	R17	
Dash Storage	J25 R3, R17	
Dashpads Degree Wedges	06, C61, R94	
Differential Cable		FL
Lock Kits	C70, X27	Ga
Differential	A13, C72, X28,	GI
Components	R24-36 A9, J43, J60, C46,	Gr
Differential Covers	C68, X14, X26	Gr
Dimmer Switches	R64	Ha Ha
Distributors & Parts	R58-59	Ha
Door Accessories	J32, C25	H
Door Glass Seals	R6 C25, R16, R21,	
Door Handles	R22-23	
Door Inserts	C25, R20	
Door Latch Brackets	R16, R19	
Door Locks	R19-23	
Door Seals	R6 C16, C18	
Door Skins Door Straps	C16, C18 C25	
Door Window Seals	R6	Hi
Doors	J32, C45	Ho
Driveshafts	04-5, J56, X15, R37,	Ho
Electrical	R112 R57-64	Н
Engine	KJ7-64	Но
Connecting Rods	R72-73	Ho
Camshaft	R73	Hu
Bearings	K/3	Id
Camshaft Position Sensors	R63	lgi In
Camshafts	R72	Se
Crankshaft Oil	R70	In
Seals	R7U	In
Crankshaft Pilot Bearings	R71	In
Crankshaft		Kr
Position Sensors	R63	Lil
Cylinder Head	R69	Li
Gaskets		Lit
Cylinder Heads Intake Manifolds	R73 R68, R70	St
Main Bearing Sets	R71	-
Mounts	R76	
Oil Lines	R74	
Oil Caps	J29, R68	
Oil Dip Sticks Oil Filters	R74 R74	
Oil Gauges	R66	
Oil Pan Drain	R68	
Plugs		
Oil Pan Gaskets	R69	
Oil Pressure Sending Units	R62	
Oil Pumps	R74	
Pistons	R41, R70	
Push Rods	R74	
Rocker Arms	R73-R74	
& Parts Timing Chains	R75	
Timing Covers	R69, R75	
Valve Covers	R3, R68-69	Lo
Valvetrain	R73	Lo
Entry Guards	J35, C25	M
Exhaust Catalytic		Mi
Converters	R78	
Catback Exhaust	J44, C55, X28	Mi
Kits		M
Hardware	R79	Sv
Headers Insulators	J44, C55, X15, R77 R79, R115	Of
Manifolds	J44, R68, R70,	OL
& Gaskets	R77-78	Ou
Intermediate	R78	Ha
Pipes Mufflers		0
Tailpipes	R79, R115 R79	O> Pe
Exterior Accessories	J37, J52, C35, X8	Pi
Fenders		8
Fender Flares	U25-26, J15, C11,	Pi
	C50, X3, R19	Pir Pc
Flat Fender Flares Pocket Flares	U25 C10	B
Replacement	R8, R12	Po
RRC Flat Fenders	C50	Ra
Flashers	R65	Re
Flex Plates	R50	Re
Floor Liners	U14-16, J24, C20, X6	Re
Floor Pans	R8-10, R12, R15	Re
Footrests	- R9	Ri

Frame Parts	R11	
Fuel Caps	R84	
EGR Valves	R81	
Carburetors	R80	
Gauges Lines	R66 R82	
PCV Valves	R81	
System	R81-84	
Components Tanks	R83	1
Fuses	R65	k
Gauges	R66	
Glove Box Doors Grab Handles	C23, R17 J35, C22	
Grille Inserts	J36, J42, C35	
Half Doors	J32	
Hard Top Insulation Hardtop Seals	J23 R7	9
Heating & AC		
A/C Compressors	R85	
A/C Condensors A/C Parts	R85, R115 R85	-
Blower Motors	R85, R116	
Heater Cables	R85	
Heater Cores Heater Hoses	R85 R53	
Heater Switches	R85	
Hitches	J53, C3	
Hood Catches Hood Lift Kits	J40, C27, C29 J53, C47, X15	
Hood Locks	J44, C50	
Horn Buttons	R86	
Horns Hose Clamps	R67 R53, R84	
Hubs	R42	
Idler Cross Shafts	R50	
Ignition Parts Intake Temperature	R60-61, R64	
Sensors	R63	
Interior Accessories	J30, C23-24, X7	
Interior Door Handles Interior Storage	C25 J26, C22	1
Interior Trim Items	J29-31, C21	
Knock Sensors	R63	
Liberty Parts License Plate Holder	X28 U18	-
Liftgate Support	R19-23	
Struts Lighting	1120 20	
Bulbs	R4-5	
Driving Lights	U22, J51, R4	
Fog Lights	U22, J51 J37, J41, J52, C28,	
Guards	C31-32, C54	
Light Bars	U24, J38, J51, C53	
Light Kits	J52, C54 U21-24, J49-52,	
Lighting	C51-54, X12-13	
Headlight Bezels	J36, J52, C35, C54, R4	
Headlights	U22 , C52, X13	
Headlight Parts	R4-5, R64	
HID & Halogen Lighting	U21, J49, C51, X12	
HID Light	U22, J50, C52, X13	2
Accessories	U22, J52, C53,	
Tail Lights	X8, R5	-
Lockers	C71, X27	2
Locking Hubs Main Shafts	U20, C12, C66, X24 R99-107	
MAP Sensors	R63	
Mini Van Parts	R111 U30, J33, C36,	
Mirrors	R9-11, R14, R16-23	
Multifunction	U23, J50, C52, X13,	
Switches	R64-65, R85 J43-44, J53, C45-	
Off Road Accessories	50, C56, X15	
Outer Door Handles	R21	
Outer Tailgate Handles	R18	
Overhead Console	J25, C24	
Oxygen Sensors Pedal Pads	R62, R116 R47	
Pinion Bearings	R24-34	1
& Seals		
Pintle Hook Pivot Bolts	R9, R11, R13 R92	
Power Brake	R32	
Boosters		
Power Steering Radio Bracket	R87-88 R14	
Rear Storage	J28	
Rearview Mirrors	C36, J33, R21	1
Recovery Gear	U18-19, J47-48, C43-44, X10-11	110
Relays		1
	R64-65	
Ring & Pinion	R64-65 A9, J60, C68, C72, X26, X28	

	Rocker Guard	J13, C5, C47
	Roll Bar Accessories	J34, C22
	RRC Side Armor	J13, C5
		A11, C70, X27, R6-7,
	Seals	R42, R70, R73, R85,
	Seats	R87 C37-40, X4
		C39, R9-10, R13,
	Seat Belts	R17, R20
	Seat Covers	J27, J31, C40, X5
	Seat Organizers	J27, X5
	Seat Protectors	J28, C41, X5
	Shackle Brackets	R92
	Shackles	07-8, C61-62, X21,
	Snackles	R92, R94
	Shift Forks	A11, C70, X27, R98-
		99, R106, R108
	Shift Knobs	X7, C21
	Shift Rods	R95-97
	Shovel Bracket	R14
	Side Marker Lights	R5
	Side Tube Steps Skid Plates	J14, C10, X2
		J43, C46, C48
	Slip Yoke Eliminator	A11, C48, C69-70, X15, X27, O5, R98
	Snorkel	J45
	Soft Tops	010
	Accessories	C13
	Bowless Top	U6, C17
	Hardware	U10-11, J22, C18,
	Island Toppers	U8, J21-22, C14-15
	Power Top	U2-3, J18-19
	Seals	R7
	Specialty Tops	U9
	Summer Briefs	U7, J20, C14
	Pocket Briefs	U7, J20-21, C13
	Windshield	J21. C13
	Channels	J21, U13
	XHD Replacement	U4-5, C16
	Tops	
	Solenoids	R58
	Sound Accessories	C19
	Spark Plugs & Wires	R61
	Speedometers	R66
	Spider Gears	A13, C72, R24-30, R32,R34, R36
1	Spindle Nut Socket	R26, R42
	Spreader Bars	U11, C18, R19
	Stainless Accessories	
	Starters	R57-58
	Steering	
	Columns	C23, R17, R87, R115
	Drag Links	J43, C49, R89-90
	Gear Box	R86-R87
	Gear Box Knuckles	R86-R87 R24, R88
		R24, R88
	Knuckles	R24, R88 R87
	Knuckles Manual Steering Gear Boxes	R24, R88 R87 J56, C49, X14,
	Knuckles Manual Steering Gear Boxes Parts	R24, R88 R87 J56, C49, X14, R86-90
	Knuckles Manual Steering Gear Boxes Parts Pitman Arms	R24, R88 R87 J56, C49, X14, R86-90 R88
	Knuckles Manual Steering Gear Boxes Parts Pitman Arms Shaft Couplings	R24, R88 R87 J56, C49, X14, R86-90 R88 R86
	Knuckles Manual Steering Gear Boxes Parts Pitman Arms Shaft Couplings Shafts	R24, R88 R87 J56, C49, X14, R86-90 R88 R88 R86 R86
	Knuckles Manual Steering Gear Boxes Parts Pitman Arms Shaft Couplings Shafts Tie Rods	R24, R88 R87 J56, C49, X14, R86-90 R88 R86 R86 C49, R89
	Knuckles Manual Steering Gear Boxes Parts Pitman Arms Shaft Couplings Shafts Tie Rods Tie Rods Tie Rod Ends	R24, R88 R87 J56, C49, X14, R86-90 R86 R86 R86 C49, R89 X14, R89-90
	Knuckles Manual Steering Gear Boxes Parts Pitman Arms Shaft Couplings Shafts Tie Rods Tie Rod Ends Wheels	R24, R88 R87 J56, C49, X14, R86-90 R88 R86 C49, R89 X14, R89-90 R86
	Knuckles Manual Steering Gear Boxes Parts Pitman Arms Shaft Couplings Shafts Tie Rods Tie Rods Tie Rod Ends Wheels Storage	R24, R88 R87 J56, C49, X14, R86-90 R88 R86 C49, R89 X14, R89-90 R86 J26-28, C19
	Knuckles Manual Steering Gear Boxes Parts Pitman Arms Shaft Couplings Shafts Tie Rods Tie Rod Ends Wheels	R24, R88 R87 J56, C49, X14, R86-90 R88 R86 C49, R89 X14, R89-90 R86
	Knuckles Manual Steering Gear Boxes Parts Pitman Arms Shaft Couplings Shafts Tie Rods Tie Rods Ends Wheels Storage	R24, R88 R87 J56, C49, X14, R86-90 R88 R86 C49, R89 X14, R89-90 R86 J26-28, C19 J25, C21, R13,
	Knuckles Manual Steering Gear Boxes Parts Pitman Arms Shaft Couplings Shafts Tie Rods Tie Rods Ends Wheels Storage Sun Visors	R24, R88 R87 J56, C49, X14, R86-90 R86 C49, R89 X14, R89-90 R86 J26-28, E19 J25, C21, R13, R17, 20
	Knuckles Manual Steering Gear Boxes Parts Pitman Arms Shaft Couplings Shafts Tie Rods Tie Rod Ends Wheels Storage Sun Visors Surplus	R24, R88 R87 J56, C49, X14, R86-90 R86 C49, R89 X14, R89-90 R86 J26-28, E19 J25, C21, R13, R17, 20
	Knuckles Manual Steering Gear Boxes Parts Pitman Arms Shaft Couplings Shafts Tie Rods Tie Rod Ends Wheels Storage Sun Visors Surplus Suspension Coil Springs Leaf Spring	R24, R88 R87 J56, C49, X14, R86-90 R88 R86 C49, R89 X14, R89-90 R86 J26-28, C19 J25, C21, R13, R17, 20 R111-116 R93-94
	Knuckles Manual Steering Gear Boxes Parts Pitman Arms Shaft Couplings Shafts Tie Rods Tie Rods Tie Rods Wheels Storage Sun Visors Surplus Suspension Coil Springs Leaf Spring Bushings	R24, R88 R87 J56, C49, X14, R86-90 R88 R86 C49, R89 X14, R89-90 R86 J26-28, C19 J25, C21, R13, R17, 20 R111-116 R93-94 92
	Knuckles Manual Steering Gear Boxes Parts Pitman Arms Shaft Couplings Shafts Tie Rods Tie Rod Ends Wheels Storage Sun Visors Surplus Suspension Coil Springs Leaf Spring	R24, R88 R87 J56, C49, X14, R86-90 R86 C49, R89 X14, R89-90 R86 J26-28, C19 J25, C21, R13, R17, 20 R11-116 R93-94 92 06-7, C61, X20, R91
	Knuckles Manual Steering Gear Boxes Parts Pitman Arms Shaft Couplings Shafts Tie Rods Tie Rod Ends Wheels Storage Sun Visors Surplus Suspension Coil Springs Leaf Spring Bushings Leaf Springs	R24, R88 R87 J56, C49, X14, R86-90 R86 C49, R89 X14, R89-90 R86 J26-28, C19 J25, C21, R13, R17, 20 R111-116 R93-94 92 06-7, C61, X20, R91 02-6, C58-61, X19,
	Knuckles Manual Steering Gear Boxes Parts Pitman Arms Shaft Couplings Shafts Tie Rods Tie Rod Ends Wheels Storage Sun Visors Surplus Surplus Coil Springs Leaf Spring Bushings Leaf Springs	R24, R88 R87 J56, C49, X14, R86-90 R88 C49, R89 J26-28, C19 J26-28, C19 J25, C21, R13, R7, 20 R111-116 R93-94 Q206-7, C61, X20, R92 Q2-6, C58-61, X19, J55-56
	Knuckles Manual Steering Gear Boxes Parts Pitman Arms Shaft Couplings Shafts Tie Rods Tie Rods Tie Rods Wheels Storage Sun Visors Surplus Surplus Coil Springs Leaf Spring Leaf Springs Leaf Springs Leaf Springs Leaf Springs	R24, R88 R87 J56, C49, X14, R86-90 R86 C49, R89 X14, R89-90 R86 J26-28, C19 J25, C21, R13, R17, 20 R111-116 R93-94 92 06-7, C61, X20, R91 02-6, C58-61, X19,
	Knuckles Manual Steering Gear Boxes Parts Pitman Arms Shaft Couplings Shafts Tie Rods Tie Rods Ends Wheels Storage Sur Visors Surplus Surplus Coil Springs Leaf Spring Bushings Leaf Springs Lift Kits Polyurethane Replacement	R24, R88 R87 J56, C49, X14, R86-90 R88 C49, R89 J26-28, C19 J26-28, C19 J25, C21, R13, R7, 20 R111-116 R93-94 Q206-7, C61, X20, R92 Q2-6, C58-61, X19, J55-56
	Knuckles Manual Steering Gear Boxes Parts Pitman Arms Shaft Couplings Shafts Tie Rods Tie Rod Ends Wheels Storage Sun Visors Surplus Suspension Coil Springs Leaf Spring Bushings Leaf Spring Lift Kits Polyurethane Replacement Parts	R24, R88 R87 J56, C49, X14, R86-90 R88 C49, R89 J26-28, C19 J25, C21, R13, R17, 20 R111-116 R93-94 92 06-7, C61, X20, R91 02-6, C58-61, X19, J55-56 08-9, C62-63, X21 R91-94
	Knuckles Manual Steering Gear Boxes Parts Pitman Arms Shaft Couplings Shafts Tie Rods Tie Rods Tie Rod Ends Wheels Storage Sur Visors Surplus Coll Springs Leaf Springs Leaf Springs Lift Kits Polyurethane Replacement Parts Shocks &	R24, R88 R87 J56, C49, X14, R86-90 R86 C49, R89 X14, R89-90 R86 J26-28, C21, R13, R17, 20 R11-116 R93-94 92 06-7, C61, X20, R91 02-6, C58-61, X19, J55-56 08-9, C62-63, X21 R91-94 03-7, C59-61, X19
	Knuckles Manual Steering Gear Boxes Parts Pitman Arms Shaft Couplings Shafts Tie Rods Tie Rod Ends Wheels Storage Sur Visors Surples Cui Springs Leaf Spring Leaf Springs Leaf Springs Leaf Springs Leaf Springs Leaf Springs Leaf Springs Stabilizers	R24, R88 R87 J56, C49, X14, R86-90 R86 C49, R89 X14, R9-90 R86 J26-28, C19 R17, 20 R11-116 R93-94 92 06-7, C61, X20, R91 02-6, C58-61, X19, S55-56 R9-94 C82-63, X21 R91-94 03-7, C55-61, X19- 20, J55-56, R91
	Knuckles Manual Steering Gear Boxes Parts Pitman Arms Shaft Couplings Shafts Tie Rods Tie Rods Ends Wheels Storage Sur Visors Surplus Surplus Coil Springs Leaf Springs Leaf Springs Leaf Springs Lift Kits Polyurethane Replacement Parts Shocks & Stabilizers Spring Bolts	R24, R88 R87 J56, C49, X14, R86-90 R88 C49, R89 J26-28, C19 J25, C21, R13, R17, 20 R111-116 R93-94 92 06-7, C61, X20, R91 02-6, C58-61, X19, J25-56 08-9, C62-63, X21 R91-94 03-7, C59-61, X19, 20, J55-56, R91 R92
	Knuckles Manual Steering Gear Boxes Parts Pitman Arms Shaft Couplings Shafts Tie Rods Tie Rod Ends Wheels Storage Sur Visors Surplus Surplus Call Spring Leaf Spring Bushings Leaf Springs Lift Kits Polyurethane Replacement Parts Shocks & Stabilizers Spring Plates	R24, R88 R87 J56, C49, X14, R86-90 R88 C49, R89 J26-28, C19 J25, C21, R13, R17, 20 R111-116 R93-94 92 06-7, C61, X20, R91 02-6, C58-61, X19, J55-56 08-9, C62-63, X21 R91-94 03-7, C59-61, X19, R92 Q3 L56 C58 V10
	Knuckles Manual Steering Gear Boxes Parts Pitman Arms Shaft Couplings Shafts Tie Rods Tie Rods Ends Wheels Storage Sur Visors Surplus Surplus Coil Springs Leaf Springs Leaf Springs Leaf Springs Lift Kits Polyurethane Replacement Parts Shocks & Stabilizers Spring Bolts	R24, R88 R87 J56, C49, X14, R86-90 R88 C49, R89 J26-28, C19 J25, C21, R13, R17, 20 R111-116 R93-94 92 06-7, C61, X20, R91 02-6, C58-61, X19, J55-56 08-9, C62-63, X21 R91-94 03-7, C59-61, X19, R92 Q3 L56 C58 V10
	Knuckles Manual Steering Gear Boxes Parts Pitman Arms Shaft Couplings Shafts Tie Rods Tie Rods Wheels Storage Surplus Surplus Call Springs Leaf Spring Leaf Springs Leaf Springs Leaf Springs Leaf Springs Leaf Springs Leaf Springs Subjurethane Replacement Parts Shocks & Stabilizers Spring Plates Steering Stabilizers Spring Plates	R24, R88 R87 J56, C49, X14, R86-90 R86 C49, R89 X14, R9-90 J26-28, C21, R13, R17, 20 R111-116 R93-94 92 06-7, C61, X20, R91 02-6, C58-61, X19, J55-56 08-9, C62-63, X21 R91-94 03-7, C59-61, X19- 20, J55-56, R91 R92 R92 C03, J56, C59, X19, R92 C03, J56, C59, X19, R92 C03, J56, C59, X19, R92 C03, J56, C59, X19, R92 C03, J56, C59, X19, R92
	Knuckles Manual Steering Gear Boxes Parts Platman Arms Shaft Couplings Shafts Tie Rods Tie Rod Ends Wheels Storage Sur Visors Surplus Suspension Coil Springs Leaf Spring Bushings Leaf Spring Bushings Leaf Springs Lift Kits Polyurethane Replacement Parts Shocks & Stabilizers Spring Blates Steering Stabilizers Steering Stabilizers Steering Stabilizers	R24, R88 R87 J56, C49, X14, R86-90 R86 C49, R89 X14, R89-90 R86 J26-28, C19 J25, C21, R13, R17, 20 R111-116 R93-94 92 06-7, C61, X20, R91 02-6, C58-61, X19, J55-56 R9-9, C62-63, X21 R91-94 03-7, C59-61, X19- 20, J55-56, R91 R92 3, O3, J56, C59, X19, R88 R89-90, R92, R94
	Knuckles Manual Steering Gear Boxes Parts Pitman Arms Shaft Couplings Shafts Tie Rods Tie Rods Ends Wheels Storage Sur Visors Surplus Surplus Coil Springs Leaf Spring Bushings Leaf Spring Bushings Shocks & Stabilizers Spring Bolts Steering Stabilizers Sway Bar End Links	R24, R88 R87 J56, C49, X14, R86-90 R88 C49, R89 J26-28, G19 J25, C21, R13, R17, 20 R111-116 R93-94 92 06-7, C61, X20, R91 02-6, C58-61, X19, J25-56 08-9, C62-63, X21 R91-94 03-7, C59-61, X19- 20, J55-56, R91 R92 G3, J56, C59, R14 R92 G3, J56, C59, R14 R92 R88 R89-90, R92, R94
	Knuckles Manual Steering Gear Boxes Parts Pitman Arms Shaft Couplings Shafts Tie Rods Tie Rods Storage Surplus Storage Surplus Coil Springs Leaf Spring Bushings Leaf Spring Bushings Leaf Springs Lift Kits Polyurethane Replacement Parts Shocks & Stabilizers Spring Bolts Spring Plates Steering Stabilizers Sway Bar End Links Tachometers Tailgate Locks	R24, R88 R87 J56, C49, X14, R86 R86 R86 C49, R89 X14, R89-90 R86 J26-28, C19, R13, R17, 20 R11-116 R93-94 92 06-7, C61, X20, R91 02-6, C58-61, X19, J25-56 08-9, C62-63, X21 R91-94 03-7, C59-61, X19- 20, J55-56, R91 R92 R92 R92 R92 R92 R92 R92 R92 R93 R93 R94 R94 R95 R95 R95 R95 R95 R95 R95 R95 R95 R95
	Knuckles Manual Steering Gear Boxes Parts Platman Arms Shaft Couplings Shafts Tie Rods Tie Rod Ends Wheels Storage Sur Visors Surplus Surplus Suspension Coil Springs Leaf Spring Bushings Leaf Springs Leaf Springs Lift Kits Polyurethane Replacement Parts Shocks & Stabilizers Spring Plates Steering Stabilizers Spring Plates Steering Stabilizers Steering Stabilizers	R24, R88 R87 J56, C49, X14, R86-90 R86 C49, R89 X14, R89-90 R86 J26-28, C19 J25, C21, R13, R17, 20 R111-116 R93-94 92 06-7, C61, X20, R91 02-6, C58-61, X19, C8-9, C62-83, X21 R91-94 03-7, C59-61, X19- 20, J55-56, R91 R92 03, J56, C59, X19, R92 C03, J56, C59, X19, R92 R89-90, R92, R94 R88 R89-90, R92, R94 R86 R3, R10-15, R18
	Knuckles Manual Steering Gear Boxes Parts Pltman Arms Shaft Couplings Shafts Tie Rods Tie Rod Ends Wheels Storage Sur Visors Surplus Surplus Coil Springs Leaf Spring Leaf Spring Leaf Spring Leaf Springs Lift Kits Polyurethane Replacement Parts Shocks & Stabilizers Spring Plates Steering Stabilizers Steering Stabilizers Stabilizers Steering Stabilizers Steering Sta	R24, R88 R87 J56, C49, X14, R86 R86 R86 C49, R89 X14, R89-90 R86 J26-28, C19, R13, R17, 20 R11-116 R93-94 92 06-7, C61, X20, R91 02-6, C58-61, X19, J25-56 08-9, C62-63, X21 R91-94 03-7, C59-61, X19- 20, J55-56, R91 R92 R92 R92 R92 R92 R92 R92 R92 R93 R93 R94 R94 R95 R95 R95 R95 R95 R95 R95 R95 R95 R95
	Knuckles Manual Steering Gear Boxes Parts Pitman Arms Shaft Couplings Shafts Tie Rods Tie Rods Tie Rods Storage Surplus Storage Surplus Surplus Coil Springs Leaf Spring Bushings Leaf Spring Bushings Leaf Spring Bushings Leaf Spring Bushings Leaf Spring Bushings Leaf Spring Bushings Shocks & Stabilizers Shocks & Stabilizers Steering Stabilizers Steering Stabilizers Sway Bar End Links Tachometers Tailgate Locks Tailgates Temperature Saudges	R24, R88 R87 J56, C49, X14, R86-90 R86 C49, R89 X14, R89-90 R86 J26-28, C19 J25, C21, R13, R17, 20 R111-116 R93-94 92 06-7, C61, X20, R91 02-6, C58-61, X19, C8-9, C62-83, X21 R91-94 03-7, C59-61, X19- 20, J55-56, R91 R92 03, J56, C59, X19, R92 C03, J56, C59, X19, R92 R89-90, R92, R94 R88 R89-90, R92, R94 R86 R3, R10-15, R18
	Knuckles Manual Steering Gear Boxes Parts Platman Arms Shaft Couplings Shafts Tie Rods Tie Rod Ends Wheels Storage Sur Visors Surplus Suspension Coll Springs Leaf Spring Bushings Leaf Spring Bushings Leaf Spring Bushings Leaf Spring Bushings Leaf Spring Bushings Leaf Spring Bushings Leaf Spring Stocks & Stabilizers Spring Plates Steering Stabilizers Spring Plates Steering Stabilizers Spring Plates Steering Stabilizers Spring Plates Steering Stabilizers Spring Plates Steering Stabilizers Spring Plates Steering Stabilizers Sway Bar End Links Tachometars Tailgate Locks Tailgate Locks Tailgate Locks Tamperature Gauges	R24, R88 R87 J56, C49, X14, R86-90 R86 C49, R89 X14, R89-90 R86 J26-28, C19 J25, C21, R13, R17, 20 R111-116 R93-94 92 06-7, C61, X20, R91 02-6, C58-61, X19, C8-9, C62-63, X21 R91-94 03-7, C59-61, X19- 20, J55-56, R91 R92 03, J56, C59, X19, R92 C03, J56, C59, X19, R92 C03, J56, C59, X19, R92 R88 R89-90, R92, R94 R86 R3, R10-15, R18 R3, R10-15, R18 R66 R63
	Knuckles Manual Steering Gear Boxes Parts Pltman Arms Shaft Couplings Shafts Tie Rods Tie Rod Ends Wheels Storage Surples Surples Surples Coil Springs Leaf Spring Bushings Leaf Spring Leaf Spring Leaf Spring Bushings Leaf Spring Stabilizers Shocks & Stabilizers Stabilizers Stabilizers Steering Stabilizers Steering Stabilizers Tailgates Temperature Sending Units	R24, R88 R87 J56, C49, X14, R86-90 R86 C49, R89 X14, R89-90 R86 J26-28, C19 J25, C21, R13, R17, 20 R111-116 R93-94 92 06-7, C61, X20, R91 02-6, C58-61, X19, C8-9, C62-63, X21 R91-94 03-7, C59-61, X19- 20, J55-56, R91 R92 Q3, J56, C59, X19, R92 R89-90, R92, R94 R88 R89-90, R92, R94 R86 R3, R10-15, R18 R3, R10-15, R18
	Knuckles Manual Steering Gear Boxes Parts Pitman Arms Shaft Couplings Shafts Tie Rods Tie Rods Tie Rods Storage Surplus Surplus Surplus Surplus Surplus Coil Springs Leaf Spring Leaf Spring Leaf Spring Leaf Springs Leaf Springs Leaf Springs Leaf Springs Leaf Springs Leaf Springs Stabilizers Shocks & Stabilizers Straigate Locks Steering Stabilizers Sway Bar End Links Tachometers Tailgate Locks Tailgate Locks Tailgates Temperature Seasors Temperature Seasors Throttle Body	R24, R88 R87 J56, C49, X14, R86-90 R86 C49, R89 X14, R89-90 R86 J26-28, C19 J25, C21, R13, R17, 20 R111-116 R93-94 92 06-7, C61, X20, R91 02-6, C58-61, X19, C8-9, C62-63, X21 R91-94 03-7, C59-61, X19- 20, J55-56, R91 R92 03, J56, C59, X19, R92 C03, J56, C59, X19, R92 C03, J56, C59, X19, R92 R88 R89-90, R92, R94 R86 R3, R10-15, R18 R3, R10-15, R18 R66 R63
	Knuckles Manual Steering Gear Boxes Parts Pitman Arms Shaft Couplings Shafts Tie Rods Tie Rod Ends Wheels Storage Surplus Stapension Coll Springs Leaf Spring Bushings Leaf Spring Bushings Leaf Springs Lift Kits Polyurethane Replacement Parts Stabilizers Spring Plates Steeling Stabilizers Spring Plates Steering Stabilizers Spring Plates Steering Stabilizers Tailgate Locks Tailgate Locks Tailgate Locks Tailgate Locks Tailgate Locks Tailgate Locks Tailgate Locks Tailgate Locks Tailgate Locks Tailgate Locks Tamperature Gauges Temperature Sensors Throttle Body	R24, R88 R87 J56, C49, X14, R86-90 R86 C49, R89 X14, R89-90 R86 J26-28, C19 J25, C52, R13, R17, 20 R11-116 R93-94 92 06-7, C61, X20, R91 02-6, C58-61, X19, C58-61, X19, C64-7, C59-61, X19- 20, J55-56, R91 03-7, C59-61, X19- 20, J55-56, R91 R92 03, J56, C59, X19, R92 G03, J56, C59, X19, R93 G03, C59, C59, C59, C59, C5
	Knuckles Manual Steering Gear Boxes Parts Pltman Arms Shaft Couplings Shafts Tie Rods Tie Rod Ends Wheels Storage Sur Visors Surplus Suspension Coil Springs Leaf Spring Bushings Leaf Spring Bushings Leaf Spring Bushings Leaf Spring Bushings Leaf Spring Stocks & Stabilizers Spring Plates Steering Stabilizers Steering Stabilizers Tailgate Locks Tailgate Locks Tailgate Locks Temperature Sensors Throttle Body Spacer Throttle Cables	R24, R88 R87 J56, C49, X14, R86-90 R86 C49, R89 X14, R89-90 R86 J26-28, C19 J25, C21, R13, R17, 20 R11-116 Q2-6, C58-61, X19, Q2-6, C58-61, X19, C55-56 Q8-9, C62-63, X21 R91-94 Q3-7, C59-61, X19- 20, J55-56, R91 Q3, J56, C59, X19, R92 Q3, J56, C59, X19, R92 Q3, J56, C59, X19, R92 Q3, S56, C59, X19, R92 Q3, J56, C59, X19, R92 Q3, J56, C59, X19, R92 R89-90, R92, R94 R89-90, R92, R94 R66 R63, R65 R63, R65 J45, C55, X16 R80
	Knuckles Manual Steering Gear Boxes Parts Parts Phitman Arms Shaft Couplings Shafts Tie Rods Tie Rods Tie Rods Tie Rods Storage Surplus Storage Surplus Leaf Spring Bushings Leaf Spring Bushings Leaf Spring Bushings Leaf Spring Bushings Leaf Spring Bushings Leaf Spring Bushings Leaf Spring Bushings Leaf Spring Bushings Leaf Spring Bushings Stabilizers Shocks & Stabilizers Surplus Botts Spring Plates Steering Stabilizers Sway Bar End Links Tachometers Tailgate Locks Tailgates Temperature Sensors Throttle Body Spacer Throttle Cobles Throttle Cobles	R24, R88 R87 J56, C49, X14, R86-90 R86 C49, R89 X14, R89-90 R86 J26-28, C19 J25, C52, R13, R17, 20 R11-116 R93-94 92 06-7, C61, X20, R91 02-6, C58-61, X19, C58-61, X19, C64-7, C59-61, X19- 20, J55-56, R91 03-7, C59-61, X19- 20, J55-56, R91 R92 03, J56, C59, X19, R92 G03, J56, C59, X19, R93 G03, C59, C59, C59, C59, C5
	Knuckles Manual Steering Gear Boxes Parts Pltman Arms Shaft Couplings Shafts Tie Rods Tie Rod Ends Wheels Storage Sur Visors Surplus Suspension Coil Springs Leaf Spring Bushings Leaf Spring Bushings Leaf Spring Bushings Leaf Spring Bushings Leaf Spring Stocks & Stabilizers Spring Plates Steering Stabilizers Steering Stabilizers Tailgate Locks Tailgate Locks Tailgate Locks Temperature Sensors Throttle Body Spacer Throttle Cables	R24, R88 R87 J56, C49, X14, R86-90 R86 C49, R89 X14, R89-90 R86 J26-28, C19 J25, C21, R13, R17, 20 R11-116 Q2-6, C58-61, X19, Q2-6, C58-61, X19, C55-56 Q8-9, C62-63, X21 R91-94 Q3-7, C59-61, X19- 20, J55-56, R91 Q3, J56, C59, X19, R92 Q3, J56, C59, X19, R92 Q3, J56, C59, X19, R92 Q3, S56, C59, X19, R92 Q3, J56, C59, X19, R92 Q3, J56, C59, X19, R92 R89-90, R92, R94 R89-90, R92, R94 R66 R63, R65 R63, R65 J45, C55, X16 R80
	Knuckles Manual Steering Gear Boxes Parts Pitman Arms Shaft Couplings Shafts Tie Rods Tie Rod Ends Wheels Storage Surplus <b>Surplus</b> <b>Surplus</b> <b>Coil Springs</b> Leaf Spring Bushings Leaf Spring Bushings Leaf Spring Bushings Leaf Spring Bushings Leaf Spring Bushings Shocks & Stabilizers Spring Plates Steering Stabilizers Spring Plates Steering Stabilizers Steering Stabilizers Tailgate Locks Tailgate Locks Tailgate Locks Tailgate Locks Tailgate Locks Tailgate Locks Tailgate Locks Tailgate Locks Tailgate Locks Tamperature Sensors Throttle Body Spacer Throttle Position Sensors	R24, R88 R87 J56, C49, X14, R86-90 R86 C49, R89 X14, R89-90 R86 J26-28, C19 J25, C21, R13, R17, 20 R11-116 Q2-6, C58-61, X19, Q2-6, C58-61, X19, C55-56 Q8-9, C62-63, X21 R91-94 Q3-7, C59-61, X19- 20, J55-56, R91 Q3, J56, C59, X19, R92 Q3, J56, C59, X19, R92 R89-90, R92, R94 R86 R63, R65 J45, C55, X16 R80 R63

Tire Carriers	J10, J44, C4, C45,
	R9-14
Tire Covers Toolbox	U8, J22, C13 R3, R11, R13
	J53, C28, C33, C56,
Tow Hooks	X14-15
Trac-Lok	R36
Track Bars Transfer Case	X14, R90, R93-94
Crossmember	X14, R8, R21
Dana 18	R95
Dana 20	R96
Dana 300 Drive Chains	R97 A11, C70, X27, R99
NP231	R98, R112
NP242	R99
NV249	R99
Quadra-Trac	R96
Transmission	
Automatics	R108, R112
AX-15	R107-108
AX-4	R105-106
AX-5	R105-106, R112
BA-10 Mounts	R105 R108
SR4	R102
Surplus	R112
Assemblies Synchronizers	R98-107
T14	R101
T15	R101
T150	R102
T176	R103 R103
T177 T18	R103
T4	R104
T5	R104
T84	R101
T90 T98	R100 R101
Tube Doors	J32, C45
Tune-Up Kits	R61
Turn Signal Switches	R64
Turn Signals U-Bolts	R5, R113, R116 A10, R91-93
U-Joints	A10, R24-27, R33,
U-JUIILS	DOC 007
um um u	R35, R37
UTV/ATV Visor Covers	U27-31
UTV/ATV Visor Covers Voltage Regulators	
Visor Covers Voltage Regulators Weatherstrip	U27-31 J25, C21
Visor Covers Voltage Regulators	U27-31 J25, C21 R65 R6-21
Visor Covers Voltage Regulators Weatherstrip	U27-31 J25, C21 R65 R6-21 A10, J17, C12, C69,
Visor Covers Voltage Regulators Weatherstrip Wheels	U27-31 J25, C21 R65 R6-21
Visor Covers Voltage Regulators Weatherstrip Wheels Adaptors	U27-31 J25, C21 R65 R6-21 A10, J17, C12, C69, X3, X26 R33, R41 R42
Visor Covers Voltage Regulators Weatherstrip Wheels Adaptors Bearings	U27-31 J25, C21 R65 R6-21 A10, J17, C12, C69, X3, X26 R33, R41 R42 A10, J17, C12, C69,
Visor Covers Voltage Regulators Weatherstrip Wheels Adaptors Bearings Lug Nuts Spacers	U27-31 J25, C21 R65 R6-21 A10, J17, C12, C69, X3, X26 R33, R41 R42 A10, J17, C12, C69, X3, X26 X3, X26
Visor Covers Voltage Regulators Weatherstrip Wheels Adaptors Bearings Lug Nuts	U27-31 J25, C21 R55 R6-21 A10, J17, C12, C69, X3, X26 R33, R41 R42 A10, J17, C12, C69, X3, X26 R33, R42 J16-17, C12, X3,
Visor Covers Voltage Regulators Weatherstrip Wheels Adaptors Bearings Lug Nuts Spacers Studs Wheels	U27-31 J25, C21 R65 R6-21 A10, J17, C12, C69, X3, X26 R33, R41 R42 A10, J17, C12, C69, X3, X26 R33, R42 J16-17, C12, X3, R9-11, R14
Visor Covers Voltage Regulators Weatherstrip Wheels Adaptors Bearings Lug Nuts Spacers Studs	U27-31 J25, C21 R55 R6-21 A10, J17, C12, C69, X3, X26 R33, R41 R42 A10, J17, C12, C69, X3, X26 R33, R42 J16-17, C12, X3,
Visor Covers Voltage Regulators Weatherstrip Wheels Adaptors Bearings Lug Nuts Spacers Studs Wheels Winch & Recovery Winch Rope	U27-31 J25, C21 R65 R6-21 A10, J17, C12, C69, X3, X26 R33, R41 R42 A10, J17, C12, C69, X3, X26 R33, R42 J16-17, C12, X3, R9-11, R14 U17-19, J46, C42, X9-11 U18
Visor Covers Voltage Regulators Weatherstrip Wheels Adaptors Bearings Lug Nuts Spacers Studs Wheels Winch & Recovery Winch Rope Window Cranks	U27-31 J25,C21 R65 R6-21 A10,J17,C12,C69, X3,X26 R33,R41 R42 A10,J17,C12,C69, X3,X26 R33,R42 J16-17,C12,X3, R9-11,R14 U17-19,J46,C42, X9-11 U18 R17,R20
Visor Covers Voltage Regulators Wheele Adaptors Bearings Lug Nuts Spacers Studs Wheels Winch & Recovery Winch Rope Window Cranks Window Regulators	U27-31 J25,C21 R55 R6-21 A10,J17,C12,C69, X3,X26 R33,R41 R42 A10,J17,C12,C69, X3,X26 R33,R42 J16-17,C12,X3, R9-11,R14 U17-19,J46,C42, X9-11 U18 R17,R20 R22,R115
Visor Covers Voltage Regulators Weatherstrip Wheels Adaptors Bearings Lug Nuts Spacers Studs Wheels Winch & Recovery Winch Rope Window Cranks Window Regulators Windshield Frames	U27-31 J25, C21 R65 R6-21 A10, J17, C12, C69, X3, X26 R33, R41 R42 A10, J17, C12, C69, X3, X26 R33, R42 A10, J17, C12, C69, X3, X26 R33, R42 J16-17, C12, X3, R9-11, R14 U17-19, J46, C42, X9-11 U18 R17, R20 R22, R115 R8,R11-12, R14-15, R18
Visor Covers Voltage Regulators Weatherstrip Wheels Adaptors Bearings Lug Nuts Spacers Studs Wheels Winch & Recovery Winch Rope Winch Rope Window Cranks Window Regulators Windshield Frames Windshield Seals	U27-31 J25, C21 R65 R6-21 A10, J17, C12, C69, X3, X26 R33, R42 A10, J17, C12, C69, X3, X26 R33, R42 A10, J17, C12, C69, X3, X26 R33, R42 A10, J17, C12, C69, X3, X26 R33, R42 H17, R20 R17, R20 R2, R11-12, R14-15, R8,R11-12, R14-15,
Visor Covers Voltage Regulators Weatherstrip Wheels Bearings Lug Nuts Spacers Studs Wheels Winch & Recovery Winch Rope Window Cranks Window Regulators Windshield Frames Windshield Seals Wipers	U27-31 J25,C21 R65 R6-21 A10,J17,C12,C69, X3,X26 R33,R41 A10,J17,C12,C69, X3,X26 R33,R42 J16-17,C12,X3, R9-11,R14 U17-19,J46,C42, X9-11 U18 R17,R20 R22,R15 R8,R11-12,R14-15, R18 R6-7,R9,R11
Visor Covers Voltage Regulators Weatherstrip Wheels Adaptors Bearings Lug Nuts Spacers Studs Wheels Winch & Recovery Winch Rope Window Cranks Windshield Frames Windshield Frames Windshield Seals Wipers Arms	U27-31 J25, C21 R65 R6-21 A10, J17, C12, C69, X3, X26 R33, R41 R42 A10, J17, C12, C69, X3, X26 R33, R42 A10, J17, C12, C69, X3, X26 R33, R42 J16-17, C12, X3, R9-11, R14 U17-19, J46, C42, Y9-11 U18 R17, R20 R22, R15 R8, R11-12, R14-15, R18 R6-7, R9, R11
Visor Covers Voltage Regulators Weatherstrip Wheels Bearings Lug Nuts Spacers Studs Wheels Winch & Recovery Winch Rope Window Cranks Window Regulators Windshield Frames Windshield Seals Wipers	U27-31 J25,C21 R65 R6-21 A10,J17,C12,C69, X3,X26 R33,R41 A10,J17,C12,C69, X3,X26 R33,R42 J16-17,C12,X3, R9-11,R14 U17-19,J46,C42, X9-11 U18 R17,R20 R22,R15 R8,R11-12,R14-15, R18 R6-7,R9,R11
Visor Covers Voltage Regulators Weatherstrip Wheels Adaptors Bearings Lug Nuts Spacers Studs Wheels Winch & Recovery Winch Rope Window Cranks Window Cranks Window Regulators Windshield Frames Windshield Frames Blades Motors Switches	U27-31 J25, C21 R65 R6-21 A10, J17, C12, C69, X3, X26 R33, R41 R42 A10, J17, C12, C69, X3, X26 R33, R42 J16-17, C12, C69, X3, X26 R33, R42 J16-17, C12, X3, R9-11, R14 U17-19, J46, C42, X9-11 U17-19, J46, C42, X9-11 U17-19, J46, C42, X9-11 U17-19, J46, C42, X9-11 U17 R17, R20 R22, R115 R8, R11-12, R14-15, R18 R6-7, R3, R11 R110
Visor Covers Voltage Regulators Wheele Regulators Wheele Adaptors Bearings Lug Nuts Spacers Studs Wheels Winch & Recovery Winch & Recovery Winch & Recovery Winch & Recovery Window Cranks Window Cranks Windshield Frames Windshield Seals Wipers Arms Blades Motors Switches Washer Fluid Level	U27-31 J25,C21 R65 R6-21 A10,J17,C12,C69, X3,X26 R33,R41 A10,J17,C12,C69, X3,X26 R33,R42 J16-17,C12,X3, R9-11,R14 U17-19,J46,C42, X9-11 U18 R17,R20 R22,R15 R8,R11-12,R14-15, R110 R109,R115-116
Visor Covers Voltage Regulators Weatherstrip Wheels Adaptors Bearings Lug Nuts Spacers Studs Wheels Winch & Recovery Winch Rope Window Cranks Window Cranks Window Regulators Windshield Frames Windshield Frames Blades Motors Switches	U27-31 J25,C21 R65 R6-21 A10,J17,C12,C69, X3,X26 R33,R41 R42 A10,J17,C12,C69, X3,X26 R33,R42 J16-17,C12,X3, R9-11,R14 U17-19,J46,C42, X9-11 U18 R17,R20 R22,R115 R8,R11-12,R14-15, R18 R6-7,R9,R11 R109 R109 R109 R109
Visor Covers Voltage Regulators Weatherstrip Wheels Adaptors Bearings Lug Nuts Spacers Studs Wheels Winch & Recovery Winch Rope Window Cranks Window Regulators Windshield Frames Windshield Frames Windshield Frames Blades Motors Switches Washer Fluid Level Sensors Windshield Winshield	U27-31 J25,C21 R65 R6-21 A10,J17,C12,C69, X3,X26 R33,R41 R42 A10,J17,C12,C69, X3,X26 R33,R42 J16-17,C12,C83, R9-11,R14 U17-19,J46,C42, X9-11 U18 R17,R20 R22,R115 R8,R11-12,R14-15, R18 R6-7,R9,R11 F109,R115-116 R109 R109 R109 R109 R109
Visor Covers Voltage Regulators Weatherstrip Wheels Adaptors Bearings Lug Nuts Spacers Studs Wheels Winch & Recovery Winch Rope Window Cranks Window Cranks Window Regulators Windshield Frames Windshield Frames Windshield Frames Blades Motors Switches Washer Fluid Level Sensors Windshield	U27-31 J25,C21 R65 R6-21 A10,J17,C12,C69, X3,X26 R33,R41 A10,J17,C12,C69, X3,X26 R33,R42 J16-17,C12,X3, R9-11,R14 U17-19,J46,C42, X9-11 U18 R17,R20 R22,R15 R8,R11-12,R14-15, R10 R109,R115-116 R109 R109 R109 R109 R110
Visor Covers Voltage Regulators Weatherstrip Wheels Adaptors Bearings Lug Nuts Spacers Studs Wheels Winch & Recovery Winch Rope Window Cranks Window Regulators Windshield Frames Windshield Frames Windshield Frames Blades Motors Switches Washer Fluid Level Sensors Windshield Winshield	U27-31 J25, C21 R65 R6-21 A10, J17, C12, C69, X3, X26 R33, R42 A10, J17, C12, C69, X3, X26 R33, R42 A10, J17, C12, C69, X3, X26 R33, R42 J16-17, C12, X3, R9-11, R14 U17-19, J46, C42, X9-11 U18 R17, R20 R22, R15 R8, R11-12, R14-15, R10 R109, R115-116 R109 R109 R109 R109 R109 R109 R109 R109
Visor Covers Voltage Regulators Weatherstrip Wheels Adaptors Bearings Lug Nuts Spacers Studs Wheels Winch & Recovery Winch Rope Window Cranks Window Regulators Windshield Frames Windshield Frames Windshield Frames Blades Motors Switches Washer Fluid Level Sensors Windshield Washer Pumps Windshield	U27-31 J25,C21 R65 R6-21 A10,J17,C12,C69, X3,X26 R33,R41 A10,J17,C12,C69, X3,X26 R33,R42 J16-17,C12,X3, R9-11,R14 U17-19,J46,C42, X9-11 U18 R17,R20 R22,R15 R8,R11-12,R14-15, R10 R109,R115-116 R109 R109 R109 R109 R110
Visor Covers Voltage Regulators Weatherstrip Wheels Adaptors Bearings Lug Nuts Spacers Studs Wheels Winch & Recovery Winch Rope Window Cranks Window Regulators Windshield Frames Windshield Frames Windshield Frames Blades Motors Switches Washer Fluid Level Sensors Windshield Washer Pumps Windshield	U27-31 J25, C21 R65 R6-21 A10, J17, C12, C69, X3, X26 R33, R42 A10, J17, C12, C69, X3, X26 R33, R42 A10, J17, C12, C69, X3, X26 R33, R42 J16-17, C12, X3, R9-11, R14 U17-19, J46, C42, X9-11 U18 R17, R20 R22, R15 R8, R11-12, R14-15, R10 R109, R115-116 R109 R109 R109 R109 R109 R109 R109 R109
Visor Covers Voltage Regulators Weatherstrip Wheels Adaptors Bearings Lug Nuts Spacers Studs Wheels Winch & Recovery Winch Rope Window Cranks Window Regulators Windshield Frames Windshield Frames Windshield Frames Blades Motors Switches Washer Fluid Level Sensors Windshield Washer Pumps Windshield	U27-31 J25, C21 R65 R6-21 A10, J17, C12, C69, X3, X26 R33, R42 A10, J17, C12, C69, X3, X26 R33, R42 A10, J17, C12, C69, X3, X26 R33, R42 J16-17, C12, X3, R9-11, R14 U17-19, J46, C42, X9-11 U18 R17, R20 R22, R15 R8, R11-12, R14-15, R10 R109, R115-116 R109 R109 R109 R109 R109 R109 R109 R109
Visor Covers Voltage Regulators Weatherstrip Wheels Adaptors Bearings Lug Nuts Spacers Studs Wheels Winch & Recovery Winch Rope Window Cranks Window Regulators Windshield Frames Windshield Frames Windshield Frames Blades Motors Switches Washer Fluid Level Sensors Windshield Washer Pumps Windshield	U27-31 J25, C21 R65 R6-21 A10, J17, C12, C69, X3, X26 R33, R42 A10, J17, C12, C69, X3, X26 R33, R42 A10, J17, C12, C69, X3, X26 R33, R42 J16-17, C12, X3, R9-11, R14 U17-19, J46, C42, X9-11 U18 R17, R20 R22, R15 R8, R11-12, R14-15, R10 R109, R115-116 R109 R109 R109 R109 R109 R109 R109 R109

J: Wrangler 07-12 C: CJ& Wrangler 07-06 X: Cherokee/Grand Cherokee 84-12 R: Replacement Parts U: Accessories O: ORV<sup>TM</sup>

A: Alloy USA® R80